

HOE MOET U FOTOBEBANG BEHANGEN?

ONDERGROND – ONDERGRONDVOORBEREIDING

De ondergrond moet droog, glad, schoon en gelijkmatig zuigend zijn. Bij donkere ondergrond kan de ondergrond in het behang doorschijnen! Deze kleurverschillen dienen eerst geneutraliseerd te worden. Beslist niet op oud behang werken! Ruwe ondergronden, gaten en oneffenheden egaliseren. Als de ondergrond snel en veel vocht opneemt, behandel deze dan eerst voordat u hier op gaat behangen. Doordat de ondergrond te veel vocht opneemt zal de lijm niet houden en kan het behang loslaten en/of verschuiven. (bij twijfel of vragen, bel ons)

TEMPERATUUR

Laat het behang 8 uur drogen in dezelfde temperatuur als deze is behangen. Aanbevolen is een normale kamertemperatuur.

NIET HET BEHANG INLIJMEN

De lijm met een roller of borstel gelijkmatig op de muur verdelen en het droge behang op de ingelijmde muur aanbrengen. Gebruik hiervoor de aanbevolen lijm!

Bij banen van 46,5cm, 75 of 150cm: De lijm dient op een breedte van iets meer dan één baan op de muur aangebracht te worden. De eerste baan hierop loodrecht plaatsen en met een gummiroller of spatel aandrukken om eventuele luchtbellen te verwijderen. Dit herhaalt u per baan. De banen moeten stotend behangen worden, deze zijn niet overlappend!

LET OP!

Eventuele lijmvlakken kunt u met een droge doek zacht weg deppen.

Heel belangrijk: spoel de doek vaak uit, zodat de lijm die op het doek zit niet verder uitgeveegd wordt. Laat het behang drogen, als er dan nog lijmvlakken aanwezig zijn dan kan u deze nogmaals wegvegen zoals hierboven beschreven.

- 1 ZORG VOOR EEN SCHONE EN GLADDE ONDERGROND.
- 2 ZUIGENDE ONDERGRONDEN EERST VOORBEHANDELEN MET EEN ZUIGINGS-REMMEND VOORSTRIJKMIDDEL.
- 3 ZORG VOOR EEN EGAAL KLEURIGE ONDERGROND. VLIESBEHANG KAN DOORSCHIJNEN.
- 4 LAAT HET BEHANG EEN DAG DROGEN OP DEZELFDE KAMERTEMPERATUUR ALS TIJDENS HET BEHANGEN.
- 5 GEBRUIK ALTIJD DE AANBEVOLEN LIJM. BRENG DE LIJM AAN OP DE MUUR EN NIET OP HET BEHANG.
- 6 BRENG HET BEHANG AAN OP DE MUUR EN STRIJK DIT GLAD MET EEN DOEK OF ROLLER.
- 7 LIJMVLEKKEN METEEN WEGDEPPEN MET EEN DROGE DOEK.



Als u onze "Perfax" lijm heeft besteld, dan kunt u die vinden binnenin de rol.



Seamless



Good colour fastness



Strippable



Paste the wall



Washable

HOW TO PROCESS A PHOTO WALLPAPER?

BASIC PREPARATION SUBSURFACE

The Subsurface must be dry, smooth, clean and evenly water-absorbent. On dark-colored background, the background can be reflected in the wallpaper! These color differences should first be neutralized. Definitely do not work on top of old wallpaper! Equalize rough surfaces, holes and irregularities. If the surface is highly water-absorbent, treat it first. If the surface is highly water-absorbent, the glue will not hold and can release, and/or shift the wallpaper. (In case of doubt or questions, call us)

TEMPERATURE OF THE ROOM

Allow the wallpaper to dry for at least 8 hours at the same temperature as it was processed. Recommended is a basic room temperature.

APPLICATION – DO NOT PUT GLUE ON THE WALLPAPER

Apply the glue with a roller or a brush onto the wall and apply the dry wallpaper on the glued wall. Use a recommended glue for this!

With strips of 46,5 cm, 75cm or 150cm: The glue should be put on the wall a little bit over the width of one strip. Apply the first strip perpendicular on the wall and press with rubber rollers or spatulas to remove any airbubbles. Repeat this for each of the strips. The strips have to be applied against each other, they do not overlap!

WATCH OUT!

Any glue stains can be removed by dabbing with a sponge/cloth. **Very important:** make sure the cloth is often rinsed out. This ensures that the glue in the cloth does not get wiped out any further. Let the wallpaper dry, if there is still some glue stains left after that, you can remove these using the same method as described above.

- 1 PROVIDE A CLEAN AND SMOOTH UNDERGROUND
- 2 IF THE SURFACE IS HIGHLY WATER-ABSORBENT, FIRST TREAT WITH A PRIMER.
- 3 COLOR DIFFERENCES SHOULD FIRST BE NEUTRALIZED
- 4 ALLOW THE WALLPAPER TO DRY FOR A DAY AT THE SAME TEMPERATURE AS IT WAS PROCESSED
- 5 ALWAYS USE THE RECOMMENDED GLUE. APPLY THE GLUE TO THE WALL AND NOT ON THE WALLPAPER.
- 6 APPLY THE WALLPAPER TO THE WALL AND SWEEP IT SMOOTHLY WITH A CLOTH OR ROLLER.
- 7 GLUE STAINS CAN BE REMOVED BY DABBING WITH A SPONGE/CLOTH



If you ordered our "Perfax" glue, you can find it inside the roll.



Seamless



Good colour fastness



Strippable



Paste the wall



Washable